

Please follow the instructions below to fit your product.

### Retrimming Your Seat Base

#### To remove the old cover:

- All the components you require for installation are included, apart from seat belt top mounting brackets.
- Turn the seat base upside down. Release the two metal tabs at the rear to free the rear panel.
- Remove & retain the steel rod insert.
- Along the side, remove & retain the six black plastic pins (three per side).
- Remove & retain the rubber finishing strip, from around the main frame of the seat base.
- Remove old cover & discard.



#### To re-trim the seat base:

1. If replacing the foam, remove and discard. Glue the new foam to the steel cushion pan.
2. Turn the new cover inside out.



3. Centralise the new cover to ensure the front & rear will fit. Glue the **centre panel (ONLY)** in place.



4. Leave for a short time for the glue to set. Roll the sides of the cover down over the foam, so as to cover:



5. Using the rubber finishing strip (retained from removing the old cover) carefully trap the sewn-in cord back into the metal slot all of the way around the frame. Use a hammer or mallet. Be careful not to hit too hard or you may tear the cover:



6. Replace the plastic pins; the vinyl will need to be spiked in the appropriate place.

7. Put the metal rod back into the rear panel. You retained this when taking the old cover off.

8. Tie off the spare cord, cut away any excess & tuck under the foam.

9. Pull over the rear panel & tap down the two metal tabs.

### Retrimming Your Seat Back

#### To remove the old cover:

- Remove the headrest
- Pull apart the plastic finisher at the bottom of the backrest
- Pull the cover up over the seat
- When the cover is two thirds of the way up, release the three metal hooks and the cover can be removed

#### To re-trim the seat back:

1. Start with the new cover inside out



2. Push one third of the cover inside itself & pull over the top of the seat

3. Attach with the zip ties provided



4. Alternating from side to side, pull the rest of the cover down over the foam. Work the cover into correct position, by sliding your hands from top to bottom a few times.



5. Tuck the spare flaps in around the foam at the bottom, to act as a finisher:

6. Pull the front and back panels together at the bottom; fix in position with the plastic finisher:

Watch our fitting video online:

<http://www.exmoortrim.co.uk/videos.html>

If you require any more information on our products please contact us.

Office: +44 (0)1984 635 060

Fax: +44 (0)1984 633 539

